

» Front Panel



- ❶ Network (primary,secondary) LED
- ❷ OLED display
- ❸ Display mode switch
- ❹ Power LED

» Rear Panel



- ❶ DC adapter connection terminal
- ❷ Contact closure output terminal
- ❸ PX-6216 / ECS-6216P connection terminal
- ❹ Audio input terminal
- ❺ Audio output terminal
- ❻ Network (secondary) connection terminal
- ❼ Network (primary) connection terminal
- ❽ Factory reset switch