


The CRM 203S-RF is a tri-element boundary layer through table cardioid condenser microphone, with a built-in mechanism that will allows users to retract the microphone fully into the table. The microphone is fitted with a RGB electronic capacitive touch sensitive switch designed to be used for remote switching. Available in black Nextel (CRM 203S-RF) or satin nickel (CRM 203SN-RF).



Switch Features

- RGB electronic capacitive touch switch facilitating click/pop free switching.
- Programmable via a DSP to display up to seven colour combinations and operate in PTT, PTM or Latching modes.
- Works only in conjunction with supplied TS-C1 touch switch controller that
 accepts 6 way colour coded ribbon cable from RGB LEDs, a 2 way phoenix
 connector for connection to the reed switch and TS-OUT for connection to a
 DSP via a CAT-5 Ethernet cable.

Microphone features

- Cardioid polar pattern.
- Balanced output that is immune to RF artifacts.
- Fitted with a magnetic reed switch that prevents unwanted feedback while retracted; contact status available via TS-C1.
- Power requirements 9-48V phantom power.
- Cables 3 x 2m 2 core + screen.

Note: Reed switch status shall be used by DSP for muting.

Installation guide

- 1) Drill a 58mm (2.25") hole through the table (Fig A).
- 2) Remove the nut and fit the microphone through the hole (Fig B).
- 3) Replace nut and tighten to the underside of the table (Fig C).
- 4) Microphone connections: mic A white cable in line with screws, mic B (90 deg from mic A) black cable and mic C (90 deg from mic A) black cable with red tag. For the three mics, Red Phase +, White Phase and screen Ground.

Note: microphone screen and TS-C1 ground must have a common ground connection.



Fig A

5) TS-C1's TS-OUT wiring for connection to DSP:



Fig B



Fig C

Pin number	Function
1	Switch (Low indicating contacts closed on
	RS-IN)
2	Red LED (pulled low to illuminate
3	Ground
4	+12V DC
5	Touch Switch Activated
6	Green LED (pulled low to illuminate)
7	Blue LED (pulled low to illuminate
8	No connection

- 6) Grey 2 core (red and blue wires) connected to TS-C1's RS-IN.
- 7) Using p-clamps provided fix cables to the underside of the table ensuring there is sufficient slack in the cable loom for the mic to operate (Fig D).
- 8) Affix TS-C1 under table.
- © Clockaudio. All rights reserved.




Fig D, key:

- 1) Head in raised position.
- Loop cable allowing at least 25mm (1") out of the bottom of the CRM.
- 3) Fit supplied P-clamp using self-tap screws.
- 4) White audio cable mic A.
- 5) Black audio cable mic B.
- 6) Black with red tag audio cable mic C.
- 7) 6 way colour coded RGB switch wires.
- 8) Securing nut.
- 9) Grey switch cable red and blue cores.